



**174 TEAM TRACK ROAD, UNIT 2 AUBURN, CA 95603  
PHONE 530.887.8297 FAX 530.887.8299**

INSTALLATION INSTRUCTIONS FOR ALL TOMAHAWK FENDER TIPS

STEP1: USE EITHER DUCK TAPE OR MASKING TAPE AND TAPE THE SIDE OF THE TIPS WHICH CONTACTS FENDER. THE TAPE WILL LOWER THE RISK OF SCRATCHING THE PAINT, GREAT CAUTION SHOULD STILL BE USED WHEN FITTING THE TIP.

STEP2: SLIDE THE TIP FROM THE BOTTOM OF THE FENDER UP. YOU MAY NEED TO GENTLY SPREAD THE TIP OPEN TO SLIDE OVER THE FENDER. ALL FENDERS VARY SLIGHTLY TOMAHAWK BILLET FENDER TIPS ARE DESIGNED TO ACCOMMODATE THIS. (ON 99-01 CHIEFS, FRONT FENDER TIPS SHOULD SLIDE UP AND LINE UP WITH THE CHROME TRIM. YOU WILL NEED TO TRIM THE CHROME TRIM BACK AND IT SHOULD CONTACT THE EDGE OF THE TIP IF DONE CORRECTLY)

STEP 3: WHEN FITTING THE TIP GENTLY PRESS IN THE MIDDLE ON THE FACE OF THE TIP TO GAIN CONTACT. 6SP VICE GRIPS WITH TAPED FEET OR C-CLAMPS WITH TAPED FEET TO HELP HOLD IN PLACE ARE NOT RECOMMENDED. ONCE TIP IS IN DESIRED POSITION USE A 7/64" DRILL TO DRILL FASTENERS HOLES.

STEP4: INSERT FASTENERS IN DRILLED HOLES AND GENTLY TIGHTEN.

EARLY 1999 MODEL CHIEFS MAY HAVE ANOMAILES AND TIPS MAY NOT FIT CORRECTLY.

ALL PARTS SHOULD BE INSTALLED BY A TRAINED INDIAN SERVICE TECH. ANY QUESTIONS PLEASE CONTACT NEAREST DEALER OR TOMAHAWK DIRECTLY.



**174 TEAM TRACK ROAD, UNIT 2 AUBURN, CA 95603  
PHONE 530.887.8297 FAX 530.887.8299**

INSTALLATION INSTRUCTIONS FOR ALL TOMAHAWK FENDER TIPS

STEP1: USE EITHER DUCK TAPE OR MASKING TAPE AND TAPE THE SIDE OF THE TIPS WHICH CONTACTS FENDER. THE TAPE WILL LOWER THE RISK OF SCRATCHING THE PAINT, GREAT CAUTION SHOULD STILL BE USED WHEN FITTING THE TIP.

STEP2: SLIDE THE TIP FROM THE BOTTOM OF THE FENDER UP. YOU MAY NEED TO GENTLY SPREAD THE TIP OPEN TO SLIDE OVER THE FENDER. ALL FENDERS VARY SLIGHTLY TOMAHAWK BILLET FENDER TIPS ARE DESIGNED TO ACCOMMODATE THIS. (ON 99-01 CHIEFS, FRONT FENDER TIPS SHOULD SLIDE UP AND LINE UP WITH THE CHROME TRIM. YOU WILL NEED TO TRIM THE CHROME TRIM BACK AND IT SHOULD CONTACT THE EDGE OF THE TIP IF DONE CORRECTLY)

STEP 3: WHEN FITTING THE TIP GENTLY PRESS IN THE MIDDLE ON THE FACE OF THE TIP TO GAIN CONTACT. 6SP VICE GRIPS WITH TAPED FEET OR C-CLAMPS WITH TAPED FEET TO HELP HOLD IN PLACE ARE NOT RECOMMENDED. ONCE TIP IS IN DESIRED POSITION USE A 7/64" DRILL TO DRILL FASTENERS HOLES.

STEP4: INSERT FASTENERS IN DRILLED HOLES AND GENTLY TIGHTEN.

EARLY 1999 MODEL CHIEFS MAY HAVE ANOMAILES AND TIPS MAY NOT FIT CORRECTLY.

ALL PARTS SHOULD BE INSTALLED BY A TRAINED INDIAN SERVICE TECH. ANY QUESTIONS PLEASE CONTACT NEAREST DEALER OR TOMAHAWK DIRECTLY.